

Cutting Master 5 / Graphtec Studio 2

Repeat Cross Cut function

OPSCMGs-AUM-151

1.1 When you want to cut sheets from a roll of paper by repeatedly cross cutting

Using the cross cut function of the FC9000 Series, you can cut out a specified length and number of sheets from roll paper.


Operating Procedure

1. If you are using Cutting Master 5, specify FC9000 on the "Cutting Master 5" screen and open the "Plotter Information" tab.
If you are using Graphtec Studio 2, specify FC9000 on the "Cutting View" screen and open the "Plotter Information" tab.



This function cannot be used with models other than FC9000.

2. Make sure "Advanced Feature" - "Repeat Cross Cut" is displayed.
If it is not displayed, make sure that the cutting plotter connected to the computer is FC9000 (firmware version 1.38 or later).



3. In "Copies", specify the number of sheets you want to cut from the roll.
4. In "Length", specify the length of the cut paper you want to cut out from the roll.
5. Click the "OUTPUT" button.

Cross Cuts are repeated according to the specified "Copies" and "Length" to cut the paper from the roll.

Supplement 

- Depending on the usage environment, media type, or if a short length is specified in the "Length" item, cross cut media may not fall into the basket and may remain in the front guide. As this may result in problems such as media jams, please test the operation with a small number of sheets before using this function.
- If the media feed method is set to "SHEET", cross cutting is not possible.
- For other explanations regarding "Cross Cut", refer to the FC9000 user's manual.