



30 days FREE trial is available

G-REMOTE

REMOTE CONTROL AND DATA STORAGE SERVICE

- ✓ Easy remote control of GL260/GL860 from a web browser.
- ✓ Simple and easy-to-use control screen.
- ✓ Easy setup by same menu design as the data logger.
- ✓ All communications are encrypted.



The service starts from 10 countries and will be expanded to other area sequentially.
(the U.S., UK, Germany, France, Italy, Korea, Malaysia, Thailand, Taiwan and Japan.)



Specification

PLAN		Free Trial	Basic 1 unit monitoring	Standard Max. 5 units monitoring	Premium Max. 10 units monitoring
Period of Use	30 days from the first day of login		360 days after activation		
Remote control function	Supported models	GL260/GL860 (*Optional wireless LAN unit (B-568) is required.) * B-568 is available in limited region.			
	Remote control service	✓	✓	✓	✓
	Number of remotely connected units (Data logger)	1	1	5	10
	Remote display	✓	✓	✓	✓
	CSV playback	✓	✓	✓	✓
	Download timer	✓	✓	✓	✓
	Data storage function	Supported models	GL7000/GL2000/GL980/GL840/GL240/GL260/GL860		
File storage function (Server capacity)		1GB	1GB	5GB	10GB
Number of simultaneous accesses *1 (Data logger, PC)		3	3	15	30

*Only one PC can be connected to the Remote control function at the same time.

*There is no need to fix the PC to be used since G-REMOTE is a web application software.

*Internet and communication environment must be provided by users.

*The usage period of the paid version includes the remaining period of the free trial.

*30 days will be added if not using the free trial version.


*1 The number of simultaneous server accesses is one connection each from data loggers and PCs.

• Due to the possibility of equipment or PC failure, the data files on the instrument will not be guaranteed to be held on the memory.

Please make a back up of data whenever possible to avoid data loss.

• Brand names and product names listed in this brochure are the trademarks or registered trademarks of their respective owners.

• Items mentioned are subject to change without notice. For more information about product, please check the web site or contact your local representative.

 For using equipment in correctly and safely

- Before using it, please read the user manual and then please use it properly in accordance with the description.
- To avoid malfunction or an electric shock by current leakage or voltage, please ensure a ground connection and use according to the specification.